UZIN PROBLEM SOLUTION:

INSTALLING LUXURY VINYL TILES EXTREMELY QUICKLY ONTO OLD SUBSTRATES.

With UZIN NC 172 BiTurbo and UZIN KE 66.

When renovating floors, the installation should be as short as possible. UZIN NC 172 BiTurbo rapid drying levelling compound can be used to create substrates extremely quickly, making it the first choice for projects with short deadlines. The self-levelling compound is ready for foot traffic and can accept textile and resilient floor coverings after approx. 60 minutes. Thanks to its very high compressive strength class (C50), it can also withstand the highest loads. Its very smooth surface often makes sanding unnecessary and ensures low adhesive consumption.

„Renovations are possible within one day, as UZIN NC 172 BiTurbo dries extremely quickly."

Valentin Zeiler
Technical services UZIN

RENOPLAN SYSTEM

INSTALLING LUXURY VINYL TILES EXTREMELY QUICKLY ONTO OLD SUBSTRATES.
UZIN HAS A SOLUTION WITH RENOPLAN SYSTEM.

Remove existing floor covering. Use a Wolff grinding machine to remove any poorly adhering layers that could impair adhesion.

Vacuum thoroughly with an industrial vacuum cleaner.

Apply UZIN expansion strips to all vertical structures, such as walls, columns, heating pipes, door frames, etc. This prevents acoustic bridges and stresses resulting from rigid bonding.

Apply a thin and even coat of UZIN PE 260 dispersion primer over the entire surface using a UZIN nylon fibre roller and allow to dry for approx. 60 minutes.

Mix UZIN NC 172 Bi-Turbo rapid drying levelling compound with clear cold water. Use a powerful electric levelling compound mixer for mixing, e.g. the WOLFF Power X 1600 mixer.

Pour the mixed levelling compound onto the prepared area and spread an even coat using a smoothing trowel or the WOLFF screed rake, notch size R2. Then use an UZIN spike roller for aeration.

After approx. one hour, mark out the reference line. Then apply the fibre-reinforced UZIN KE 66 solution adhesive with a A2 notched trowel (up to the reference line).

After a short time, install the floor covering along the reference line without twisting or contorting and press down firmly by hand.

After installation, roll over with a WOLFF pressure roller.

The video is available on the UZIN YouTube Channel.

UZIN | A brand of Uzin Utz Group
Uzin Utz AG | Dieselstrasse 3 | 89079 Ulm | Telephone +49 731 4097-0 | Telefax +49 731 4097-110 | E-mail info@uzin.com | Internet www.uzin.com

12.2019/ms